

# Multi-Foci Acoustic Field Generation Using Dammann Gratings for Phased Array Transducers

Tatsuki Fushimi<sup>1, 2</sup>


1) Institute of Library, Information and Media Science, University of Tsukuba, Kasuga 1-2, Tsukuba, Ibaraki, 305-0051

2) R&D Center for Digital Nature, University of Tsukuba, Kasuga 1-2, Tsukuba, Ibaraki, 305-0051


## 1. Dammann Gratings Generation Steps

### Step 1: Generate 1D Dammann Gratings


#### Transition Points



### Step 2: Create 2D array for by mirroring by the axis and stacking it




### Step 3: Add two gratings together, and process the overlapping parts.



We took method used by SSPIM<sup>1</sup> to process the overlapping part.


### Step 4: Take the closest interpolation to create Dammann Grating Hologram




In this paper, we only explore axisymmetric gratings in x and y directions, but a Dammann grating with different gratings for x and y axis can also be generated.

<sup>1</sup> <https://github.com/aakhtemostafa/SSPIM>

## 2. Figure 2 - Raw pressure field version












## 3. Comparison of $n_p = 5$ field (ideal and PAT version)





The pressure field is not well reconstructed for peaks of 5 but the acoustic field in principle is well recovered.

#### 4. Hologram and 3D isosurface visualization of selected grating Figure 3

$n_p$	Hologram 0  $\pi$	3D Visualization Isosurface of Normalized Pressure ( $p = 0.325 \times 0.707$ )
4		
5		
8		
9		

12




## 5. Translation and Rotation of Dammann Grating




To demonstrate the translation and rotation of the Damman grating,  $n_p = 4$  Damman grating and single focus was combined.


### Translation



### Rotation



## 6. Combining Optimized Lens and Dammann Grating



Here, IBP optimizer based on Marzo & Drinkwater [5] was used to generate single focus and two focus holograms. These were generated for the ideal PAT with 81 by 81 transducers. Although the IBP hologram is calculated correctly, it does not combine well with the Dammann Gratings, even for a single focus case.